

Ultrad instructions for use

Ultrad ULTRADIFFUSION® is a non-pyrotechnic, slow combustion technology which works by diffusing the active substance in the air through a thermokinetic effect. ULTRADIFFUSION® enables uniform, very high density diffusion of the whole volume of the room to be treated, including hard-to-access zones, with precise dose to volume adjustment. Being MPI C42 rated, there is no need to rinse after treatment, food preparation can begin immediately after the last step below.



Step 1
Deactivate smoke detectors and photoelectric eyes



Step 2
Close all exits to the room being treated



Step 3
Turn off any ventilation in and out of the room being treated



Step 4
De-compact the powder by reverting the container several times before opening



Step 5
Place the can on a heat resistant surface and remove any combustible material within 1.5mtrs



Step 6
Remove the cover and light the wick with a torch lighter for at least 8 secs until it starts to smoulder
Note: always start off with the can furthest away from the exit



Step 7
Leave the building



Step 8
Put a warning on all accesses to inform treatment is in progress



Step 9
Minimum contact time is 4 hours, optimal is 15 hours



Step 10
Ventilate the premises with fresh air for a minimum of 1 hour



Step 11
The premises may be re-entered once contact time and ventilation have been completed



Step 12
Dispose of spent container. No rinsing of surfaces is required